



**NSA Sunvisor System for Cessna
Columbia 300/350/400**

Date	Revision	Approved
04/03/08	B	GH

Kit R1381000-0 Cessna 300/350/400 without Bracket/Adhesive
Kit R1381000-3 Cessna 300/350/400 with Bracket/Adhesive

Drawing List 1381000-DL

Doc. #9050-0138-002

1381000-0	1381000-3	PART NUMBER	REF P/N	DESCRIPTION	REV
	1	1381000	R1381000	Complete System W/ Bracket/Adhesive	B
1		1381000		Complete System w/o Bracket/Adhesive	B
1	1	1381100-1, -2	R1381100-1,-2	Mount Assembly Kit	B
2	2	1381101		Mount	A
2	2	1381102		Swivel °40	A
	2	1381300	R1381300	Bracket Assembly	B
	2	1381301		Bracket	A
	1	1381400	R1381400	Adhesive Kit	A
	1	1381401		Bracket Mounting Template	A
2	2	1020100-001	R1020100-001	NSA Modified Block Assembly	E
2	2	1020002-001		Modified 'A' Block	K
2	2	1020003-001		Modified 'B' Block	M
2	2	1010000-5		Complete Slide Assembly	D
2	2	1010001-5		Female Slide – Universal	F
2	2	1010002-3		Male Slide – Universal	J
2	2	R1010003		Lens Strip	B
2	2	1381201	R1381201	Lens	A
1		9051-0138-002		Installation Instructions without Bracket/Adhesive	A
	1	9051-0138-003		Installation Instructions with Bracket/Adhesive	A