

## Cessna

150/F150/A150/FA150	Original OEM P/N	Mid-State/Parker P/N	Qty
Brake, LH	S1167-4-0100	111417-4S-0101	1
	S1167-4-0114	111417-4S-0114	1
	S1167-4-0114	111417-4S-0114	1
Brake, RH	S1167-4-0100	111417-4S-0101	1
	S1167-4-0080	111417-4S-0080	1
	S1167-4-0080	111417-4S-0080	1
Union to Brake	S1167-4-0100	111417-4S-0101	2
	S1167-4-0100	111417-4S-0101	2
Fuel Hose, Carb to Strainer	S1167-6-0230	111417-6S-0230	1
	S1167-6-0230	111417-6S-0230	1
	S1167-6-0230	111417-6S-0230	1
	S1167-6-0230	111417-6S-0230	1
	S1167-6-0194	111417-6S-0194	1
	S1167-6-0194	111417-6S-0194	1
	S1167-6-0194	111417-6S-0194	1
	S1167-6-0194	111417-6S-0194	1
MLG Hose	S1167-4-0100	111417-4S-0101	1
	S1167-4-0100	111417-4S-0101	1
Oil Cooler Hose	S1236-6-0094	156001-6D-0094	1
	S1236-6-0094	156001-6D-0094	2
	S1236-6-0094	156001-6D-0094	1
	S1236-6-0094	156001-6D-0094	2
	S1236-6-0094	156001-6D-0094	2
	S1236-6-0074	156001-6D-0074	1
Oil Pressure	S1236-3-0150	156001-3S-0150	1
	S1236-3-0150	156001-3S-0150	1
	S1236-3-0150	156001-3S-0150	1
	S1236-3-0150	156001-3S-0150	1
Starter to Engine	S1167-6-0230	111417-6S-0230	1
<b>172/F172/P172</b>	<b>Original OEM p/n</b>	<b>Mid-State/Parker p/n</b>	<b>Qty</b>
Brake, Master Cyl to Elbow, LH	S1167-4-0100	111417-4S-0101	1
	S1167-4-0100	111417-4S-0101	1
	S1167-4-0100	111417-4S-0101	1
Brake, Master Cyl to Elbow, RH	S1167-4-0080	111417-4S-0080	1
	S1167-4-0080	111417-4S-0080	1
	S1167-4-0080	111417-4S-0080	1

Carburetor to Strainer	S1167-6-0180	111417-6S-0180	1
	S1167-6-0254	111417-6S-0254	1
	S1167-8-0240	111417-8D-0240	1
	S1167-8-0240	111417-8D-0240	1
	S1167-6-0220	111417-6S-0220	1
Strainer to Carburetor	S1167-6-0230	111417-6S-0230	1
	S1167-6-0254	111417-6S-0254	1
	S1167-8-0240	111417-8D-0240	1
	S1167-8-0220	111417-8D-0220	1
MLG Hose	S1167-4-0080	111417-4S-0080	1
	S1167-3-0080	MS28741-3-0080	1
	S1167-4-0080	111417-4S-0080	1
	S1167-3-0080	MS28741-3-0081	1
Oil Cooler - Floatplane	S1167-8-0340	111417-8D-0340	1
	S1167-8-0320	111417-8D-0320	1
Engine to Cooler	S1167-6-0260	111417-6S-0260	1
	S1167-6-0260	111417-6S-0260	1
	S1167-6-0260	111417-6S-0260	1
Cooler to Engine	S1167-6-0290	111417-6S-0290	1
	S1167-6-0210	111417-6S-0210	1
	S1167-6-0210	111417-6S-0210	1
Adapter to Oil Sump - Floatplane	S1167-8-0160	111417-8D-0160	1
Oil Pressure	S1236-3-0184	156001-3S-0184	1
	S1236-3-0184	156001-3S-0184	1
Dilution Valve to Engine	S1167-4-0164	111417-4S-0164	1
Horizontal Gyro to Relief Valve/Firewall	S1168-6-35	193000-6D-0035	1
	S1168-6-15	193000-6D-0015	1
Directional Gyro to Suction Gauge	S1168-4-30	193000-4D-0030	1
	S1168-4-30	193000-4D-0030	1
Oil Cooler	AE3663161H0144	124J001-8CR-0144	1
	AE3663161H0140	124J001-8CR-0140	1
	AE3663161H0184	124J001-8CR-0184	1
	AE3663161H0184	124J001-8CR-0184	1
<b>177</b>	<b>Original</b>	<b>Mid-State/Parker</b>	
	<b>OEM p/n</b>	<b>p/n</b>	<b>Qty</b>
Master Cylinder to Elbow, LH	S1167-3-0094	MS28741-3-0094	1
Master Cylinder to Elbow, RH	S1167-3-0122	MS28741-3-0122	1
Brake Hose	S1167-3-0054	MS28741-3-0054	2

Oil Cooler to Engine	S1167-6-0290	111417-6S-0290	1
Engine to Oil Cooler	S1167-6-0260	111417-6S-0260	1
Engine to Oil Cooler	S1167-6-0220	111417-6S-0220	1
Oil Cooler to Engine	S1167-6-0290	111417-6S-0290	1

<b>180</b>	<b>Original OEM p/n</b>	<b>Mid-State/Parker p/n</b>	<b>Qty</b>
Brake Line LH	S1167-4-0100	111417-4S-0101	1
	S1167-3-0100	MS28741-3-0100	1
Brake Line RH	S1167-4-0100	111417-4S-0101	1
	S1167-4-0080	111417-4S-0080	1
	S1167-3-0085	MS28741-3-0085	1
Brake Line, Main Landing Gear	S1167-4-0120	111417-4S-0120	2
Fuel Strainer to Carburetor	S1167-8-0120	111417-8D-0120	1
Fuel, Misc	S1167-8-0120	111417-8D-0120	1
Oil Pressure	S1167-4-0388	111417-4S-0388	1
Oil Filter	S1167-4-0300	111417-4S-0300	2

<b>182/A182</b>	<b>Original OEM p/n</b>	<b>Mid-State/Parker p/n</b>	<b>Qty</b>
Brake, Master Cylinder to Elbow, LH	S1167-4-0100	111417-4S-0101	1
	S1810-1000	N/A	1
	S1167C3-0100	N/A	1
	S2178C1-0083	N/A	1
Brake, Master Cylinder to Elbow, RH	S1167-4-0100	111417-4S-0101	1
	S1167-4-0080	111417-4S-0080	1
	S1167-4-0090	111417-4S-0090	1
	S1810-1000	N/A	1
	S1167C3-0100	N/A	1
	S2178C1-0083	N/A	1
Fuel Strainer to Carburetor	S1167-8-0120	111417-8D-0120	1
	S1167-8-0120	111417-8D-0120	1
	S1167-8-0120	111417-8D-0120	1
Fuel Pressure, Carb to Firewall	S2495-3-0144	124J001-3CR-0144	1
	AE3663819B0144		
Oil Pressure	S1167-4-0460	111417-4S-0460	1
	S1236-4-0460	156001-4S-0460	1
	S1236-4-0495	156001-4S-0495	1
	S1167-4-0460	111417-4S-0460	1
	S1236-4-0460	156001-4S-0460	1

Firewall to Engine	S1167-4-0388	111417-4S-0388	1
	S1167-4-0388	111417-4S-0388	1
<b>185</b>	<b>Original</b>	<b>Mid-State/Parker</b>	
	<b>OEM p/n</b>	<b>p/n</b>	<b>Qty</b>
Brake Line, Main Landing Gear	S1167-4-0120	111417-4S-0120	2
	S1167-4-0100	111417-4S-0101	2
Brake, Master Cylinder to Elbow, LH	S1167-4-0100	111417-4S-0101	1
	S1167-3-0100	MS28741-3-0100	1
Brake, Master Cylinder to Elbow, RH	S1167-4-0080	111417-4S-0080	1
	S1167-3-0085	MS28741-3-0085	1
Fuel, Misc	S1167-6-0270	111417-6S-0270	1
	S1236-6-0130	156001-6D-0130	1
	S1236-4-0144	156001-4S-0144	1
Fuel Pressure	S1236-3-0294	124J001-3CR-0294	1
Fuel to Engine Pump	S1167-6-0270	111417-6S-0270	1
Oil Pressure	S1236-4-0440	156001-4S-0440	1
	S1236-4-0415	156001-4S-0415	1
Engine to Firewall, Fuel Pressure	S1236-3-0294	124J001-3CR-0294*	1
Valve to Engine Oil Pump	S1236-4-0194	156001-4S-0194	1
	S1236-4-0290	156001-4S-0290	1
<b>188/A188</b>	<b>Original</b>	<b>Mid-State/Parker</b>	
	<b>OEM p/n</b>	<b>p/n</b>	<b>Qty</b>
Brake	S1167-4-0124	111417-4S-0124	2
Brake	S1167-4-0150	111417-4S-0150	2
Fuel, Inlet to Strainer	S1167-6-0280	111417-6S-0270	1
Vapor Return Line	S1236-4-0074	156001-4S-0440	2
Manifold Pressure	S1168-2-15		1
Oil Pressure	S1236-4-0460	156001-4S-0460	1
Oil Sump Drain	S1236-6-0130	156001-6D-0130	1
Fuel Hose	S1236-12-0174		1
Fuel Hose	S1236-6-0040		1
Fuel Hose	S1236-6-0081		1
Fuel Hose	S1234-4-0074		1
Strainer to Engine Pump	S1167-6-0280	111417-6S-0280	1

206/T206/U206/TU206/P206/TP206	Original OEM p/n	Mid-State/Parker p/n	Qty
Brake Hoses, Misc	S1167-4-0064	111417-4S-0064	1
Fuel, Misc	S1167-8-0300	111417-8D-0300	1
	S1236-4-0290	156001-4S-0290	1
	S1167-8-0300	111417-8D-0300	1
	S1236-4-0290	156001-4S-0290	1
	S1167-8-0120	111417-8D-0120	1
	S1167-8-0300	111417-8D-0300	1
	S1236-4-0290	156001-4S-0290	1
Fuel, Check Valve to Elbow	S1236-4-0150	156001-4S-0150	1
	S1236-4-0150	156001-4S-0150	1
	S1236-4-0150	156001-4S-0150	1
MLG Hose	S1167-4-0120	111417-4S-0120	1
	S1167-4-0080	111417-4S-0080	1
	S1167-4-0120	111417-4S-0120	1
	S1167-4-0080	111417-4S-0080	1
Oil Pressure	S1236-4-0270	156001-4S-0270	1
	S1236-4-0270	156001-4S-0270	1
	S1236-4-0380	156001-4S-0380	1
	S1236-4-0450	156001-4S-0450	1
	S1236-4-0270	156001-4S-0270	1
	S1236-4-0380	156001-4S-0380	1
	S1236-4-0450	156001-4S-0450	1
Oil Dilution	S1236-4-0290	156001-4S-0290	1
	S1236-4-0180	156001-4S-0180	1
	S1236-4-0290	156001-4S-0290	1
	S1236-4-0180	156001-4S-0180	1
	S1236-4-0290	156001-4S-0290	1
	S1236-4-0180	156001-4S-0180	1
Turbocharger, Misc Hoses	S1236-4-0234	156001-4S-0234	1
	S1236-4-0234	156001-4S-0234	1
	S1167-8-0240	111417-8D-0240	1
Turbocharger, Oil Pressure to Turbine	S1236-4-0310	156001-4S-0310	1
	S1236-4-0310	156001-4S-0310	1
Exhaust, Misc Hoses	S1236-4-0310	156001-4S-0310	1
	S1236-6-0094	156001-6D-0094	1
	S1236-6-0550	156001-6D-0500	1
	S1236-6-0120	156001-6D-0120	1
	S1236-4-0310	156001-4S-0310	1
	S1236-6-0094	156001-6D-0094	1
	S1236-6-0550	156001-6D-0500	1

210/T210	Original OEM p/n	Mid-State/Parker p/n	Qty
Brake, LH	S1167-3-0152	MS28741-3-0152	1
Brake, RH	S1167-3-0144	MS28741-3-0144	1
Fuel	S1167-4-0114	111417-4S-0114	1
	S1167-6-0116	111417-6S-0116	1
	S1167-8-0120	111417-8D-0120	1
	S1236-4-0150	156001-4S-0150	1
	S1236-8-0110	156001-8D-0110	1
	S1236-4-0150	156001-4S-0150	1
	S1236-8-0110	156001-8D-0110	1
Oil Pressure	S1167-4-0240	111417-4S-0240	1
	S1236-4-0380	156001-4S-0380	1
	S1236-4-0450	156001-4S-0450	1
Oil Pressure to Turbine	S1236-4-0310	156001-4S-0310	1
Oil Pressure to Transducer	S1236-4-0290	156001-4S-0290	1
Oil Dilution	S1236-4-0290	156001-4S-0290	1
	S1236-4-0180	156001-4S-0180	1
Oil, Misc	S1236-4-0234	156001-4S-0234	2
	S1236-4-0234	156001-4S-0234	1
	S1236-4-0100	156001-4S-0100	1
	S1236-4-0260	156001-4S-0260	1
	S1236-4-0280	156001-4S-0280	1
	S1236-4-0234	156001-4S-0234	2
	S1236-4-0100	156001-4S-0100	1
	S1236-4-0260	156001-4S-0260	1
	S1236-4-0280	156001-4S-0280	1
Engine Primer	S1236-4-0290	156001-4S-0290	1
	S1236-4-0080	156001-4S-0080	1
	S1236-4-0234	156001-4S-0234	1
	S1236-4-0100	156001-4S-0100	1
	S1236-4-0234	156001-4S-0234	1
	S1236-4-0100	156001-4S-0100	1
Vacuum	S1236-8-0160	156001-8D-0160	1
	S1236-8-0160	156001-8D-0160	1
Turbocharger	S1236-4-0234	156001-4S-0234	1
	S1167-8-0290	111417-8D-0290	1
	S1167-8-0240	111417-8D-0240	1

Exhaust Valve	S1236-4-0350	156001-4S-0350	1
	S1236-6-0580	156001-6D-0580	1
	S1236-4-0310	156001-4S-0310	1
	S1236-6-0550	156001-6D-0550	1
	S1236-6-0094	156001-6D-0094	1
	S1236-6-0120	156001-6D-0120	1
Hydraulic Powerpack	S1236-8-0164	156001-8D-0164	1
	S1236-4-0160	156001-4S-0160	1
	S1236-4-0106	156001-4S-0106	1
	S1236-8-0174	156001-8D-0174	1
	S1236-4-0150	156001-4S-0150	1
	S1236-8-0164	156001-8D-0164	1
	S1236-4-0106	156001-4S-0106	1
	S1236-8-0174	156001-8D-0174	1
	S1236-4-0150	156001-4S-0150	1
Pump Pressure	S1167-4-0324	111417-4S-0324	1
			1
Nose Gear Door Open	S1167-4-0180	111417-4S-0180	1
			1
Nose Gear Door Close	S1167-4-0110	111417-4S-0110	1
			1
Main Gear Door Open	S1167-4-0074	111417-4S-0074	2
			2
Main Gear Door Close, RH	S1167-4-0146	111417-4S-0146	1
			1
Main Gear Door Close, LH	S1167-4-0172	111417-4S-0172	1
			1
Hydraulic System	S1167-3-0104	MS28741-3-0104	4
Hydraulic System	S1167-4-0124	111417-4S-0124	1
			1
Hydraulic System	S1167-4-0140	111417-4S-0140	1
			1
Hydraulic System	S1236-4-0150	156001-4S-0150	1
			1
Hydraulic System	S1236-4-0042	156001-4S-0042	1
			1
Hydraulic System	S1236-4-0110	156001-4S-0110	1
			1

**Note #1**

\* for a/c with crosswind landing gear

**Note #2**

Not used on TU206 series

**Note #3**

Not used on TP206 series

**Note #4**

For use on floatplanes only

**Note #5**

For use on floatplanes only

**Beechcraft**

<b>35, A35</b>	<b>Original OEM P/N</b>	<b>Mid-State/Parker P/N</b>	<b>Qty</b>
Manifold Pressure	AN6270-4-28	193000-4D-0280	1
	AN6270-4-9	193000-4D-0090	1
Fuel Unit to Pump	AN6270-6-8	193000-6D-0080	1
Carburetor Vent Return, FWD	AN6270-4-11	193000-4D-0110	1
Manifold Pressure, FWD	AN6270-4-9	193000-4D-0090	1
Strut, Brake	AN6271-4-15-3/4	193000-4D-0156	2
Master Cylinder	AN6271-4-10	193000-4D-0100	2
	AN6271-4-10-7/8	193000-4D-0107	1
	AN6271-4-12	193000-4D-0120	1
<b>B35</b>	<b>Original OEM P/N</b>	<b>Mid-State/Parker P/N</b>	<b>Qty</b>
Manifold Pressure	AN6270-4-9	193000-4D-0090	1
Fuel Unit to Pump	AN6270-6-8	193000-6D-0080	1
Carburetor Vent Return, FWD	AN6270-4-11	193000-4D-0110	1
Manifold Pressure, FWD	AN6270-4-9	193000-4D-0090	1
Strut, Brake	AN6271-4-15-3/4	193000-4D-0156	2
Master Cylinder	AN6271-4-10	193000-4D-0100	2
	AN6271-4-10-7/8	193000-4D-0107	1
	AN6271-4-12	193000-4D-0120	1
<b>C35</b>	<b>Original OEM P/N</b>	<b>Mid-State/Parker P/N</b>	<b>Qty</b>
Manifold Pressure	AN6270-4-9	193000-4D-0090	1
Fuel Unit to Pump	AN6270-6-8	193000-6D-0080	1
Carburetor Vent Return, FWD	AN6270-4-11	193000-4D-0110	1



Manifold Pressure, FWD	AN6270-4-9	193000-4D-0090	1
Strut, Brake	AN6271-4-15-3/4	193000-4D-0156	2
Master Cylinder	AN6271-4-10	193000-4D-0100	2
	AN6271-4-10-7/8	193000-4D-0107	1
	AN6271-4-12	193000-4D-0120	1

<b>D35</b>	<b>Original OEM P/N</b>	<b>Mid-State/Parker P/N</b>	<b>Qty</b>
Manifold Pressure	AN6270-4-9	193000-4D-0090	1
Fuel Unit to Pump	AN6270-6-8	193000-6D-0080	1
	MS28741-6-076	111417-6S-0076	1
Carburetor Vent Return, FWD	AN6270-4-11	193000-4D-0110	1
	MS28741-4-110	111417-4S-0110	1
Manifold Pressure, FWD	AN6270-4-9	193000-4D-0090	1
Strut, Brake	AN6271-4-15-3/4	193000-4D-0156	2
Master Cylinder	AN6271-4-10	193000-4D-0100	2
	AN6271-4-10-7/8	193000-4D-0107	1
	AN6271-4-12	193000-4D-0120	1

<b>E35</b>	<b>Original OEM P/N</b>	<b>Mid-State/Parker P/N</b>	<b>Qty</b>
Manifold Pressure	AN6270-4-9	193000-4D-0090	1
Fuel Unit to Pump	MS28741-6-076	111417-6S-0076	1
Carburetor Vent Return, FWD	MS28741-4-110	111417-4S-0110	1
Manifold Pressure, FWD	AN6270-4-9	193000-4D-0090	1
Strut, Brake	AN6271-4-15-3/4	193000-4D-0156	2
Master Cylinder	AN6271-4-10	193000-4D-0100	2
	AN6271-4-10-7/8	193000-4D-0107	1
	AN6271-4-12	193000-4D-0120	1

<b>F35</b>	<b>Original OEM P/N</b>	<b>Mid-State/Parker P/N</b>	<b>Qty</b>
Manifold Pressure	AN6270-4-9	193000-4D-0090	1
Fuel Unit to Pump	MS28741-6-076	111417-6S-0076	1
Carburetor Vent Return, FWD	MS28741-4-110	111417-4S-0110	1
Manifold Pressure, FWD	AN6270-4-9	193000-4D-0090	1
Strut, Brake	AN6271-4-15-3/4	193000-4D-0156	2

Master Cylinder	AN6271-4-10	193000-4D-0100	2
	AN6271-4-10-7/8	193000-4D-0107	1
	AN6271-4-12	193000-4D-0120	1

<b>G35</b>	<b>Original OEM P/N</b>	<b>Mid-State/Parker P/N</b>	<b>Qty</b>
Manifold Pressure	AN6270-4-9	193000-4D-0090	1
Fuel Unit to Pump	MS28741-6-076	111417-6S-0076	1
Carburetor Vent Return, FWD	MS28741-4-110	111417-4S-0110	1
Manifold Pressure, FWD	AN6270-4-9	193000-4D-0090	1
Strut, Brake	AN6271-4-15-3/4	193000-4D-0156	2
Master Cylinder	AN6271-4-10	193000-4D-0100	2
	AN6271-4-10-7/8	193000-4D-0107	1
	AN6271-4-12	193000-4D-0120	1

<b>V35B &amp; V35B-TC</b>	<b>Original OEM P/N</b>	<b>Mid-State/Parker P/N</b>	<b>Qty</b>
Main Landing Gear, Lower	MS28741-4-0170	111417-4S-0170	1
Brake Pedal, LH & RH, Pilot	MS28741-4-0107	111417-4S-0107	2
Brake Pedal, LH, Copilot	MS28741-4-0130	111417-4S-0130	1
Brake Pedal, RH, Copilot	MS28741-4-0107	111417-4S-0107	1
Oil Pressure	130524-3-0160	124F001-3S-0160	1
	130524-3-0124	124F001-3S-0124	1
Manifold Pressure	130524-3-0124	124F001-3S-0124	1
	MS28741-4-0180	111417-4S-0180	1
Fuel Pressure	130524-4-0160	111F417-4S-0160	1
	130524-4-0130	111F417-4S-0130	1
	130524-4-0160	111F417-4S-0160	2
Vapor Return	130524-4-0170	111F417-4S-0170	1
Fuel Supply	130524-6-0185	111F417-6S-0185	1
Air Sensing	MS28741-4-0254	111417-4S-0254	1
Fuel Flow & Manifold Pressure	AN6270-4-15 1/2	193000-4D-0154	1
	AN6270-23-3/4	193000-4D-0236	1
Fuel Pressure	AN6270-4-22 1/2	193000-4D-0224	1

Fuel, Misc	130524-4-0130	111F417-4S-0130	1
	130524-4-0160	111F417-4S-0160	1
	130524-6-0185	111F417-6S-0185	1
	130524-4-0170	111F417-4S-0170	1
	MS28741-3-0170	MS28741-3-0170	1
	330995F4-0060	130F001-4S-0060	1

## Mooney

M20J	Original OEM P/N	Mid-State/Parker P/N	Qty
Brake, FWD	94B-07-000-04F-0100	111502-4S-0100	1
	94B-01-000-04F-0084	111417-4S-0084	1
	94B-07-000-04F-0117	111502-4S-0117	1
Dual Brake	MS28741-4-0080	111417-4S-0080	2
	MS28741-4-0114	111417-4S-0114	2
Manifold Pressure	MES180-B000D0180F	MS28741-3-0180	1
	MS28741-3-0174	MS28741-3-0174	1
Fuel Pressure	660157-501	156003-3S-0210	1
	MS28741-3-0454	MS28741-3-0454	1
	600375-027	156F001-3S-0170	1
	912040-501	124F001-3CR-0290	1
Oil Cooler	156F001-8D0204	156F001-8D0204	1
	156F062E0320D000	156F062E0320D000	1
Oil Pressure	MS28741-4-0150	111417-4S-0150	1
	600375-027	156F001-3S-0170	1
	912040-503	124F001-3CR-0170	1
	660157-503	156003-4S-0444	1

## Piper

PA-28-140	Original OEM P/N	Mid-State/Parker P/N	Qty
Brake	63901-17	111417-4S-0404	2
Hand Brake	63901-09	111417-4S-0110	1
Toe Brake	63901-09	111417-4S-0110	2
	63901-21	111417-4S-0162	1
	63901-29	111417-4S-0186	1
	63901-22	111417-4S-0050	1
Primer Line	17766-06	193000-2D-0072	1
	63901-77	193000-3D-0072	1
Fuel System Hose	63901-12	111417-6S-0220	1
	63901-14	111417-6S-0107	1

Pressure Gauge	63901-07	111F417-3S-0074	1
Electric Pump to Engine Pump	63901-18	111417-6S-0184	1
Electric Pump to Engine Pump	63901-12	111417-6S-0220	1
Engine Oil to Radiator, Left & Right	63901-72, 63901-163	124F001-8CR-0460	4
	63901-69, 63901-164	124F001-8CR-0500	4
Receiver Dehydrator to Condensor	565-879	124002-3CR-0192	1

<p><b>Note #1</b> used with dual toe brake only</p> <p><b>Note #2</b> Used with 1/8" ID Hose</p> <p><b>Note #3</b> Used with 3/16" ID Hose</p>
--

PA-28-150/160	Original OEM P/N	Mid-State/Parker P/N	Qty
Brake	63901-17	111417-4S-0404	2
Brake Valve to Tee	63901-04	111417-4S-0067	1
Hand Brake	63901-09	111417-4S-0110	1
Lower Brake	63901-02	111417-4S-0342	2
Toe Brake	63901-09	111417-4S-0110	2
	63901-21	111417-4S-0162	1
Electric Pump to Carburetor	63901-05	111417-5S-0105	1
	63901-11	111417-5S-0110	1
	63901-14	111417-6S-0107	1
	63901-12	111417-6S-0220	1
Electric Pump to Engine Pump	63901-08	111417-5S-0220	1
	63901-13	111417-6S-0246	1
	63901-18	111417-6S-0184	1
Engine Pump Inlet	63901-19	111417-6S-0300	1
	63901-14	111417-6S-0107	1
	63901-12	111417-6S-0220	1
Engine Pump to Electric Pump	63901-06	111417-5S-0202	1
	63901-12	111417-6S-0220	1
Engine to Oil Radiator, Left and Right	63901-72, 63901-163	124F001-8CR-0460	4
	63901-20	111417-8D-0300	2
Fuel Line to Fuel Tank	63901-15	111F417-6S-0124	2
Gascolator to Electric Pump	63901-10	111417-5S-0174	1
	63901-12	111417-6S-0220	1
Oil Pressure Gauge	3901-27	111F417-4S-0080	1
Pressure Gauge	63901-07	111F417-3S-0074	1

Primer Line	17766-06	193000-2D-0072	1
	63901-77	193000-3D-0072	1
Reservoir to Master Cylinder	63901-03	111417-4S-0104	1

**Note #1**  
Not for use If fuel cooling kit 756-807, 759-808, 756-809 has been installed.

**Note #2**  
If Fuel Cooling kit 756-807, 756-808, or 756-809 has been installed, use P/N 111417-6S-0220

**Note #3**  
If Fuel Cooling kit 756-807, 756-808, or 756-809 has been installed, use P/N 111417-6S-0184

**Note #4**  
Used on s/ns 28-1521 thru 28-1760 If Fuel Cooling kit 756-807, 756-808, or 756-809 has been installed.

**Note #5**  
Used with 1/8" ID Hose

**Note #6**  
Used with 3/16" ID Hose

<b>PA-28-180</b>	<b>Original OEM P/N</b>	<b>Mid-State/Parker P/N</b>	<b>Qty</b>
Brake	63901-17	111417-4S-0404	2
Hand Brake	63901-09	111417-4S-0110	1
Toe Brake	63901-09	111417-4S-0110	2
	63901-22	111417-4S-0050	2
	63901-21	111417-4S-0162	1
Primer Line	17766-06	193000-2D-0072	1
	63901-77	193000-3D-0072	1
Gascolator to Electric Pump	63901-12	111417-6S-0220	1
Electric Pump to Carburetor	63901-11	111417-5S-0110	1
	63901-14	111417-6S-0107	1
	63901-12	111417-6S-0220	1
Engine Pump to Electric Pump	63901-06	111417-5S-0202	1
	63901-12	111417-6S-0220	1
Electric Pump to Engine Pump	63901-13	111417-6S-0246	1
	63901-18	111417-6S-0184	1
Oil Pressure Gauge	63901-07	111F417-3S-0074	1
	63901-27	111F417-4S-0080	
Engine to Oil Radiator, Left & Right	63901-72, 63901-163	124F001-8CR-0460	2
	63901-20	111417-8D-0300	2
Engine Pump Outlet	63901-14	111417-6S-0107	1
	63901-12	111417-6S-0220	1

Engine Pump Inlet	63901-19	111417-6S-0300	1
Fuel Line to Fuel Tank	63901-15	111F417-6S-0124	2
Oil Radiator	63901-26	111F417-8D-0210	1
	63901-43	111F417-8D-0300	1

**Note #1**  
Not for use If fuel cooling kit 756-807, 759-808, 756-809 has been installed.

**Note #2**  
If Fuel Cooling kit 756-807, 756-808, or 756-809 has been installed, use 111417-6S-0220

**Note #3**  
If Fuel Cooling kit 756-807, 756-808, or 756-809 has been installed, use P/N 111417-6S-0184

**Note #4**  
Used on s/ns 28-1521 thru 28-1760 If Fuel Cooling kit 756-807, 756-808, or 756-809 has been installed.

**Note #5**  
Used with 1/8" ID Hose

**Note #6**  
Used with 3/16" ID Hose

PA-28-235	Original OEM P/N	Mid-State/Parker P/N	Qty
Brake	63901-17	111417-4S-0404	2
Toe Brake	63901-09	111417-4S-0110	1
	63901-21	111417-4S-0162	1
Hand Brake	63901-09	111417-4S-0110	1
Fuel Line to Fuel Tank	63901-15	111F417-6S-0124	2
Engine Fuel Pump	63901-13	111417-6S-0246	2
Electric Pump to Carburetor	63901-24	111F417-6S-0246	1
Engine Pump to Electric Pump	63901-23	111F417-6S-0276	1
Carburetor to Pressure Gauge	63901-07	111F417-3S-0074	1
	63901-44	111417-4S-0050	1
Oil Radiator Inlet to Engine	63901-26	111F417-8D-0210	1
Oil Pressure Gauge	63901-27	111F417-4S-0080	1

**Note #1**  
used with dual toe brake only

PA-28-R-180/-200	Original OEM P/N	Mid-State/Parker P/N	Qty
------------------	---------------------	-------------------------	-----

Brake	63901-17	111417-4S-0404	2
Hand Brake	63901-09	111417-4S-0110	1
Toe Brake	63901-09	111417-4S-0110	1
	63901-22	111417-4S-0050	1
	63901-21	111417-4S-0162	1
Primer Line	17766-06	193000-2D-0072	1
	63901-77	193000-3D-0072	1
Fuel Line to Fuel Tank	63901-14	111417-6S-0107	1
Engine Hose, Misc	63901-36	111F417-4S-0130	1
<b>Oil Cooler</b>	<b>63901-43</b>	<b>124F001-8D-0300</b>	<b>1</b>
Main Gear Cylinder	63901-21	111417-4S-0162	2
	63901-30	111417-4S-0084	2
	63901-41	111F417-4S-0166	2
Receiver Dehydrator to Condensor	565-878	124007A0160C225	1
Discharge	565-864	124F001-6CR-0322	1

**Note #1**  
Used with 1/8" ID Hose

**Note #2**  
Used with 3/16" ID Hose

PA-28R-201/201T	Original OEM P/N	Mid-State/Parker P/N	Qty
Brake Line	63901-17	111417-4S-0404	2
Hand Brake	63901-09	111417-4S-0110	1
Toe Brake	63901-09	111417-4S-0110	2
	63901-21	111417-4S-0162	2
	63901-22	111417-4S-0050	1
Misc Power Plant	63901-36	111F417-4S-0130	1
<b>Oil Cooler</b>	<b>63901-43</b>	<b>124F001-8D-0300</b>	<b>2</b>
Fuel Line	63901-39	193000-2D-0250	1
	63901-45	111F417-3S-0380	1
	63901-41	111F417-4S-0166	1
	63901-14	111417-6S-0107	1
	63-01-38	111F417-6S-0282	1
Fuel Return	63901-30	111417-4S-0084	1
Fuel Drain	63901-78	111F417-4S-0230	1

Main Gear Cylinder	63901-21	111417-4S-0162	2
	63901-30	111417-4S-0084	2
Nose Gear Cylinder	63901-41	111F417-4S-0166	2

**Note #1**  
used with dual toe brake only

**Note #2**  
Not for use If fuel cooling kit 756-807, 759-808, 756-809 has been installed.

**Note #3**  
For use if fuel cooling kit 756-807, 756-808, or 756-809 has been installed

**Note #4**  
If Fuel Cooling kit 756-807, 756-808, or 756-809 has been installed, use P/N 63901-12

**Note #5**  
If Fuel Cooling kit 756-807, 756-808, or 756-809 has been installed, use P/N 111417-6S-0184

**Note #6**  
Used on s/ns 28-1521 thru 28-1760 If Fuel Cooling kit 756-807, 756-808, or 756-809 has been installed.

**Note #7**  
Used with 1/8" ID Hose

**Note #8**  
Used with 3/16" ID Hose

<b>PA-28-236</b>	<b>Original OEM P/N</b>	<b>Mid-State/Parker P/N</b>	<b>Qty</b>
Brake Line	63901-17	111417-4S-0404	1
Hand Brake	63901-30	111417-4S-0084	1
Toe Brake	63901-09	111417-4S-0110	2
	63901-21	111417-4S-0162	2
	63901-22	111417-4S-0050	1
Fuel Flow Pressure	63901-44	111417-4S-0050	1
Oil Pressure	63901-52	111F417-4S-0080	1
Engine Driven Pump to Carburetor	63901-24	111F417-6S-0246	1

<b>PA-32-260</b>	<b>Original OEM P/N</b>	<b>Mid-State/Parker P/N</b>	<b>Qty</b>
Brake	63901-17	111417-4S-0404	2
Hand Brake	63901-30	111417-4S-0084	1
Oil Pressure	63901-27	111F417-4S-0080	1



Oil Cooler	63901-26	111F417-8D-0210	1
Primer Line Connector	63901-77	193000-3D-0072	1
Engine Fuel Pump	63901-23	111F417-6S-0276	1
	63901-24	111F417-6S-0246	1
Carburetor to Pressure Gauge	63901-25	124F001-3CR-0160	1
Fuel Tank to Fuel Line	63901-15	111F417-6S-0124	2

<b>PA-32-300</b>	<b>Original OEM P/N</b>	<b>Mid-State/Parker P/N</b>	<b>Qty</b>
------------------	-----------------------------	---------------------------------	------------

Brake	63901-17	111417-4S-0404	2
Hand Brake	63901-30	111417-4S-0084	1
Engine Fuel Pump	63901-42	111F417-6S-0184	1
	63901-24	111F417-6S-0246	1
Fuel Flow Gauge	63901-32	124F001-3S-0114	1
	63901-40	124F001-3S-0244	1
Fuel Pressure Gauge	63901-36	111F417-4S-0130	1
Vent Fuel Flow Gauge	63901-33	193000-2D-0124	1
Oil Pressure	63901-27	111F417-4S-0080	1
Oil Cooler	63901-35	111F417-8D-0260	1
	63901-73	111F417-8D-0284	1
Outlet to Oil Cooler, Right	63901-26	111F417-8D-0210	1
Outlet to Oil Cooler, Left	63901-26	111F417-8D-0210	1
	63901-35	111F417-8D-0260	1
Main Tank to Fuel Line	63901-15	111F417-6S-0124	1

<b>PA-32R-300</b>	<b>Original OEM P/N</b>	<b>Mid-State/Parker P/N</b>	<b>Qty</b>
-------------------	-----------------------------	---------------------------------	------------

Brake	63901-17	111F417-6S-0124	2
Hand Brake	63901-30	111417-4S-0084	1

Toe Brake	63901-28	111417-4S-0150	1
	63901-09	111417-4S-0110	1
	63901-29	111417-4S-0186	2
	63901-30	111417-4S-0084	1
Nose Gear Cylinder	63901-09	1114174-4S-0110	1
	63901-31	1114174-4S-0057	1
Main Gear Cylinder	63901-21	111417-4S-0162	2
	63901-30	111417-4S-0084	2
Engine Fuel Pump	63901-24	111F417-6S-0246	1
Fuel Flow Gauge	63901-40	124F001-3s-0244	1
Fuel Pressure Gauge	63901-36	111F417-4S-0130	1
Vent Fuel Flow Gauge	63901-33	193000-2D-0124	1
Oil Cooler	63901-96	156D003-10D-0153	1
Engine to Oil Cooler	63901-99	111D504-8D-0284	1

<b>PA-34</b>	<b>Original OEM P/N</b>	<b>Mid-State/Parker P/N</b>	<b>Qty</b>
Brake Line	63901-17	111F417-6S-0124	2
Toe Brake	63901-09	111417-4S-0110	*
	63901-76	111F417-4S-0134	1
	63901-28	111417-4S-0150	1
	63901-29	111417-4S-0186	2
	63901-30	111417-4S-0084	2
	63901-31	111417-4S-0057	1
Nose Gear Extension Port	63901-28	111417-4S-0150	1
Main Gear Cylinder Extension Pots	63901-09	111417-4S-0110	2
Main Gear Cylinder Retraction Ports	63901-28	111417-4S-0150	2
Nose Gear Retraction Port	63901-70	111417-4S-0130	1
Oil Cooler Inlet	63901-66	111F417-8D-0154	2
	63901-73	111F417-8D-0284	2

Oil Cooler Outlet, Left	63901-35	111F417-8D-0260	1
Oil Cooler Outlet, Right	63901-49	111F417-8D-0210	1
Oil and Fuel Pressure, Engine	63901-56	111F417-4S-0166	4
Fuel Flow	63901-68	124F001-3S-0290	2
Fuel Hose	63901-71	111417-6S-0206	2
Fuel Supply	63901-67	111F417-6S-0133	2

**Note #1**

Qty 2 used with single toe brake, qty 1 used with dual toe brake

**Note #2**

Used with dual toe brake only

**Note #3**

Used with single toe brake only

**By Engine Model**

**IO-360 Series**

IO-360 Continental	Original OEM P/N	Mid-State/Parker P/N	Qty
Control to Fuel Pump	635158-16.00	124JT001-4CR-0160	1
Control to Manifold Valve	635158-14.00	124JT001-4CR-0140	1

TSIO-360 Continental	Original OEM P/N	Mid-State/Parker P/N	Qty
Control to Fuel Pump	635158-16.00	124JT001-4CR-0160	1
Unit to M/F	635158-16.00	124JT001-4CR-0160	1
Unit to M/F	635158-22.00	124JT001-4CR-0220	1
Turbo to C/C	635218-6-36.00	111F417-6S-0360	1
Turbo to C/C	635218-6-30.00	111F417-6S-0300	1

<b>LTSIO-3600-360</b>	<b>Original</b>	<b>Mid-State/Parker</b>	
<b>Continental</b>	<b>OEM P/N</b>	<b>P/N</b>	<b>Qty</b>
Turbo to C/C	635218-6-3600	111F417-6S-0360	1

## IO-520 Series

<b>IO-520 Series</b>	<b>Original</b>	<b>Mid-State/Parker</b>	
<b>Continental</b>	<b>OEM P/N</b>	<b>P/N</b>	<b>Qty</b>
Fuel Pump to Control	635158-14.00	124JT001-4CR-0140	1
Control to Fuel Pump	635158-10.00	124JT001-4CR-0100	1
Control to Manifold Valve	635158-32.00	124JT001-4CR-0320	1
Control to Fuel Pump Outlet & Return	635158-38.00	124JT001-4CR-03800	2
Fuel Injection Hose	635158-12.00	124JT001-4CR-0120	2
Fuel Injection Hose	635158-12.00	124JT001-4CR-0120	1
Fuel Injection Hose	635158-40.00	124JT001-4CR-0400	1
Fuel Injection Hose	635158-10.00	124JT001-4CR-0100	1

## IO-470 Series

<b>IO-470 Series</b>	<b>Original</b>	<b>Mid-State/Parker</b>	
<b>Continental</b>	<b>OEM P/N</b>	<b>P/N</b>	<b>Qty</b>
Fuel Injection Hose	MS28741-4-0340	111417-4S-0340	1
Fuel Injection Hose	MS28741-4-0266	111417-4S-0266	1
Fuel Injection Hose	MS28741-4-0300	111417-4S-0300	1
Fuel Injection Hose	MS28741-4-0160	111417-4S-0160	1
Fuel Injection Hose	MS28741-4-0160	111417-4S-0160	2
Fuel Injection Hose	MS28741-4-0084	111417-4S-0084	1
Fuel Injection Hose	MS28741-4-0044	111417-4S-0044	1
Fuel Injection Hose	MS28741-4-0370	111417-4S-0370	1
Fuel Injection Hose	MS28741-4-0180	111417-4S-0180	2
Fuel Injection Hose	MS28741-4-0330	111417-4S-0330	1
Fuel Injection Hose	635158-15.00	124JT001-4CR-0150	1
Fuel Injection Hose	635158-16.00	124JT001-4CR-0160	1
Fuel Injection Hose	635158-17.00	124JT001-4CR-0170	1
Fuel Injection Hose	635158-18.00	124JT001-4CR-0180	1
Fuel Injection Hose	635158-40.00	124JT001-4CR-0400	1
Fuel Injection Hose	MS28741-4-0150	111417-4S-0150	1
Fuel Injection Hose	MS28741-4-0130	111417-4S-0130	1
Fuel Injection Hose	MS28741-4-0320	111417-4S-0320	1

## TSIO-520 Series

<b>TSIO-520 Series</b>	<b>Original</b>	<b>Mid-State/Parker</b>	
<b>Continental</b>	<b>OEM P/N</b>	<b>P/N</b>	<b>Qty</b>
Control Assy to Fuel Pump, Outlet & Inlet	635158-13.00	124JT001-4CR-0130	2
Control to Manifold Valve	635158-36.00	124JT001-4CR-0360	1
Control to Fuel Pump Return	635158-10.00	124JT001-4CR-0100	1
Control to Fuel Pump Outlet	635158-18.00	124JT001-4CR-0180	1
Control to Fuel Pump Outlet	635158-12.00	124JT001-4CR-0120	1
Control to Manifold Valve	635158-32.00	124JT001-4CR-0320	1
Control to Fuel Pump	635158-14.00	124JT001-4CR-0140	1



**Serial Numbers****Note**

17001 thru 15061532  
15061533 thru 15067198  
F150-0001 thru F150-0259

17001 thru 15061532  
15061533 thru 15067198  
F150-0001 thru F150-0259

15062292 thru 15067198  
F150-0001 thru F150-0259

17001 thru 15072003  
F150-0001 thru F150-0658  
A15000530 thru A15000226  
FA1500001 thru FA15000081

15072004 and on  
F15000659 and on  
A1500227 and on  
FA1500082 and on

15062292 thru 15067198  
F150-0001 thru F150-0259

15065955 thru 15078526  
15078527 and on  
F15000530 thru F15000658  
F15001379 and on  
A1500686 and on

15065955 thru 15072003

15072004 and on  
F150-0659 and on  
A1500227 and on  
FA1500082 and on

17001 thru 15061532

**Note**

28000 thru 17267584  
F172-0304 thru F17201514  
P17257120 thru 17257188

28000 thru 17256512  
F172-0304 thru F17200753  
P17257120 thru P17257188

28000 thru 47746  
47747 thru 17249544  
17249545 thru 17256512  
F172-0001 thru F172-0319  
P17257120 thru P17257188

28000 thru 47746  
47747 thru 17249544  
17249545 thru 17256512  
P17257120 thru P17257188

17253843 thru 17256512  
17257162 thru 17259923  
F172-0304 thru F172-0559  
F172-0560 thru F17200753

46755 thru 17249544  
46755 thru 17249544

49545 thru 172567584  
F172-0304 thru F17201514  
P17257120 thru 17257188

17256513 thru 17260223  
172060224 thru 17267584  
F17200754 thru F17201514

46755 thru 17249544

17259044 thru 17267584  
F17200805 thru F17201514

28000 thru 17249544

47747 thru 17249544

49545 thru 17253842  
P17257120 thru 17257188

80001 thru 80058  
80059 thru 80616  
81568 and on  
11056 and on

**Note**

17700001 thru 17700839  
17700001 thru 17700839

17700001 thru 17700839

17700001 thru 17701164

17701165 thru 17701773  
17701774 and on

17701165 thru 17701773

**Note**

30000 thru 18051909  
18051910 thru 18053203

30000 thru 32150  
32151 thru 18051909  
18052385 thru 18053203

18051313 thru 18051909

30000 thru 18052384

18051184 thru 18051496

18052385 thru 18052770

18051184 thru 18051237

**Note**

33000 thru 18258399	
18258400 thru 18261539	uses AE3664056B0100
18261540 thru 18261901	uses 035018-3-0100
18261902 thru 18262465	uses AE3663231B0083

33000 thru 33842	
33843 thru 18253598	
18253599 thru 18258399	
18258400 thru 18261539	uses AE3664056B0100
18261540 thru 18261901	uses 035018-3-0100
18261902 thru 18262465	uses AE3663232B0074

33000 thru 18262465  
A182-0001 thru A182-0148  
F1820001 thru F18200025

18268078 and on

18253599 thru 18262465  
18262466 thru 18266966  
18266967 thru 18267961  
A182-0001 thru A182-0148  
F18200001 thru F18200144



18262466 thru 18262465  
F1820001 thru F18200025

		Note
185-0001 thru 185-01341		
185-1150- thru 185-1341*		1
185-0001 thru 185-1341		
185-1342 thru 18503938		
185-0001 thru 185-1341		
18502311 thru 1803938		
185-0001 thru 18504294		
185-0001 thru 18502310		
18502311 thru 18503153		
185-0001 thru 185-0653		
185-0414 thru 18503683		
185-0001 thru 18502310		
185-1389 thru 18503153		
185-0001 thru 185-0653		
185-0001 thru 185-02007, 2026, 2027		
18502008 thru 18502025, 2028, 2310		

		Note
188-0001 thru 188-0317		5
188-0001 thru 188-0317		5
188-0001 thru 18802348		
188-0001 thru 18802348		
188-0001 thru 18802119		
All		
All		
188-0001 thru 18802348		
188-0318 thru 18800745		
18800746 thru 18802348		
188-0318 thru 18800832		
188-0318 thru 18802348		

**Note**

U206-0657 thru U206-0896

206-0001 thru 206-0275  
206-0001 thru 206-0275  
U206-0276 thru U20602199  
U206-0276 thru U20603521  
U20601646 thru U20603521  
P206-0001 thru P206-0647  
P206-0001 thru P206-0647

206-0001 thru 206-0275  
U206-0276 thru U20603521  
P206-0001 thru P206-0647

U206-0657 thru U206-0897  
U206-0657 thru U206-0897  
P206-0307 thru P206-0401  
P206-0307 thru P206-0401

206-0001 thru 206-0275  
U206-0276 thru U206-0437  
U206-0438 thru U20603521  
U206-0438 thru U2061234  
P206-0001 thru P206-0160  
P206-0161 thru P206-0647  
P206-0161 thru P206-0519

2

3

206-0001 thru 206-0275  
206-0001 thru 206-0275  
U206-0276 thru U206-0437  
U206-0276 thru U206-0437  
P206-0001 thru P206-0160  
P206-0001 thru P206-0160

U206-0438 thru U206-1234  
P206-0161 thru P206-0519  
U20602200 thru U20603521

U206-1235 thru U20603521  
P206-0520 thru P206-0647

U206-0438 thru U20603521  
U206-01235 thru U20602199  
U206-0438 thru U20602199  
U20602200 thru U20603521  
P206-0161 thru P206-0647  
P206-0520 thru P206-0647  
P206-0161 thru P206-0647

**Note**

21057841 thru 21058936  
T210-0001 thru T210-0307  
21057841 thru 21058936  
T210-0001 thru T210-0307

21057841 thru 21058220  
21057841 thru 21058220  
21058221 thru 21058351  
21058819 thru 21059199  
21059200 thru 21061039  
T210-0198 thru T210-0454\*  
T210-0198 thru T210-0454

4

21057841 thru 21058715  
21058819 thru 21061039  
T210-0001 thru T210-0454

21059200 thru 21061039

21059384 thru 21061039

21057841 thru 21058715  
21057841 thru 21058715

21058819 thru 21059199  
21059200 thru 21061039  
21058819 thru 21059199  
21058819 thru 21059199  
21059200 thru 21061039  
T210-0198 thru T210-0454  
T210-0198 thru T210-0454  
T210-0198 thru T210-0454  
T210-0198 thru T210-0454

21058332 thru 21058715  
21058332 thru 21058715  
21058819 thru 21061039  
21059200 thru 21061039  
T210-0198 thru T210-0454  
T210-0198 thru T210-0454

21059200 thru 21059818  
T210-0198 thru T210-0454

T210-0001 thru T210-0197  
T210-0198 thru T210-0454  
21059648 thru 21061039

T210-0001 thru T210-0197  
T210-0001 thru T210-0197  
21059200 thru 21061039  
21059200 thru 21061039  
21059200 thru 21061039  
21059200 thru 21061039

21057841 thru 21058818  
21058086 thru 21058220  
21058462 thru 21058818  
21058819 thru 21059502  
21058819 thru 21059202  
T210-0001 thru T210-0197  
T210-0001 thru T210-0197  
T210-0198 thru T210-0454  
T210-0198 thru T210-0454

21058819 thru 21059502  
T210-0001 thru T210-454

21057841 thru 21059061  
T210-0001 thru T210-0392

21057841 thru 21059061  
T210-0001 thru T210-0392

21058221 thru 21059199  
T210-0001 thru T210-0454

21058221 thru 21059199  
T210-0001 thru T210-0454

21058221 thru 21059199  
T210-0001 thru T210-0454

21057841 thru 21058220

21057841 thru 21058818  
T210-0001 thru T210-0197

21057841 thru 21059502  
T210-0001 thru T210-0454  
21059200 thru 21059502  
21059200 thru 21059502

21059200 thru 21059502  
21059200 thru 21059502  
21059200 thru 21059502  
21059200 thru 21059502

**Serial Numbers**

D1 thru D1115

D1 thru D2200

D1 thru D2200

D1-D2200

D1 thru D2200

D1 thru D2200

D1 thru D2200

D1 thru D2200

D1 thru D2200

**Serial Numbers**

D2201 thru D2680

D2201 thru D2680

D2201 thru D2680

D2201 thru D2680

D2201 thru D2680

D2201 thru D2680

D2201 thru D2680

D2201 thru D2680

**Serial Numbers**

D2681 thru D3400

D2681 thru D3400

D2681thru D3400

D2681 thru D3400

D2681 thru D3400

D2681 thru D3400

D2681 thru D3400

D2681 thru D3400

**Serial Numbers**

D3401 thru D3698

D3401 thru D3614

D3615 thru D3698

D3401 thru D3614

D3615 thru D3698

D3401 thru D3698

D3401 thru D3698

D3401 thru D3698

D3401 thru D3698

D3401 thru D3698

**Serial Numbers**

D3699 thru D3998

D3699 thru D3998

D3699 thru D3998

D3699 thru D3998

D3699 thru D3998

D3699 thru D3998

D3699 thru D3998

D3699 thru D3998

**Serial Numbers**

D3999 thru D4391

D3999 thru D4391

D3999 thru D4391

D3999 thru D4391

D3999 thru D4391

D3999 thru D4391  
D3999 thru D4391  
D3999 thru D4391

**Serial Numbers**

D4392 thru D4865

D4392 thru D4865

D4392 thru D4865

D4392 thru D4865

D4392 thru D4865

D4392 thru D4865

D4392 thru D4865

D4392 thru D4865

**Serial Numbers**

D9069 and on

D9439, D9469 and on

D9439, D9469 and on

D9439, D9469 and on

D9069 thru D9221, D9429 thru D9775  
D9070 thru D9180

D9069 thru D9221, D9429 thru D9775  
D9222 thru D9390

D9069 thru D9221, D9391 thru D9775  
D9069 thru D9775  
D9222 thru D9390

D9069 thru D9775

D9069 thru D9775

D9222 thru D9390

D9070 thru D9180  
D9070 thru D9180

D10303 and on

D9069 thru D9221, D9391 thru D10353  
D9069 thru D9221, D9391 thru D10353  
D9069 and on  
D9069 and on  
D9069 and on  
D10354 and on

### Serial Numbers

24-0084, 24-0378 thru 24-0590  
24-0084, 24-0378 thru 24-0590  
24-0591 thru 24-0640

24-0001 thru 24-1250  
24-0001 thru 24-1250

24-1103 and on  
24-0084, 24-0259 and on

24-0001 thru 24-0083, 24-0085 thru 24-0377  
24-0001 thru 24-0083, 24-0085 thru 24-0377  
24-1379 thru 24-1417  
24-1418 and on

24-0001 and on  
24-0001 thru 24-3376

24-0001 thru 24-0377 (except 24-0084)  
24-1379 thru 24-1417  
24-1418 and on  
24-0001 thru 24-0377 except 24-0084)

### Serial Numbers

### Note

28-20002 thru 28-7725290

28-20002 thru 28-7725290

28-20002 thru 28-7725290

28-20002 thru 28-7725290

1

28-25000 thru 28-7725290

1

28-20007 thru 28-7725290

28-20002 thru 28-7725290

2

28-20002 thru 28-7725290

3

28-20002 thru 28-7725290

28-20002 thru 28-7725290



28-20002 thru 28-7725290  
28-20002 thru 28-24999  
28-25000 thru 28-7725290  
28-20002 thru 28-7125471  
28-7125472 thru 28-7725290  
  
28-7625110 thru 28-7725290

Serial Numbers	Note
28-1 thru 28-342	
28-343 thru 28-4377	
28-1 thru 28-4377	
28-1 thru 28-4377	
28-1 thru 28-4377	
28-1 thru 28-4377	
28-1 thru 28-670	2
28-671 thru 28-1058	2
28-1057 thru 28-1520	2
28-1521 thru 28-1760	
28-1 thru 28-670	3
28-671 thru 28-1520	3
28-1521 thru 28-1760	
28-1761 thru 28-4377	
28-1521 thru 28-1760	4
28-1761 thru 28-4377	
28-1 thru 28-1056	
28-1057 thru 28-1520	
28-1411 thru 28-1760	
28-1761 thru 28-4377	
28-1761 thru 28-4377	
28-511 thru 28-670	1
28-671 thru 28-4377	1
28-2478 thru 28-4377	
28-1 thru 28-1760	

28-1 thru 28-4377	5
28-1 thru 28-4377	6
28-1 thru 28-4377	

Serial Numbers	Note
28-671 thru 28-7505261	
28-671 thru 28-7505261	
28-671 thru 28-7505261	
28-671 thru 28-7505261	
28-671 thru 28-7505261	
28-671 thru 28-7505261	5
28-671 thru 28-7505261	6
28-671 thru 28-1520	1
28-671 thru 28-1056	2
28-1057 thru 28-1520	2
28-1521 thru 28-1760	
28-671 thru 28-1056*	
28-1057 thru 28-1520	
28-671 thru 28-1520	3
28-1521 thru 28-1760	
28-671 thru 28-1760	
28-2478 thru 28-7505261	
28-1411 thru 28-1760	
28-1761 thru 28-4377	
28-1521 thru 28-7505261	4
28-1761 thru 28-7505261	

28-1761 thru 28-7505261

28-1761 thru 28-7505261

28-4378 thru 28-7505261

28-4378 thru 28-7505261

<b>Serial Numbers</b>	<b>Note</b>
28-10003 thru 28-7710089	
28-10003 thru 28-7710089	1
28-10003 thru 28-7710089	1
28-10003 thru 28-7710089	
28-10003 thru 28-7710089	
28-10003 thru 28-10719	
28-10720 thru 28-7710089	
28-10720 thru 28-7710089	
28-10003 thru 28-11039	
28-11040 thru 28-771089	
28-10003 thru 28-7710089	
28-10667 thru 28-7710089	

<b>Serial Numbers</b>	<b>Note</b>
-----------------------	-------------

28R-30005 thru 28R-7635545

28R-30005 thru 28R-7635545

28R-30005 thru 28R-7635545

28R-30005 thru 28R-7635545

28R-30005 thru 28R-7635545

28R-30005 thru 28R-7635112 1

28R-30005 thru 28R-7635112 2

28R-30005 thru 28R-7635545

28R-30005 thru 28R-7635545

28R-30005 thru 28R-7635545

28R-30005 thru 28R-7635545

28R-30005 thru 28R-7635545

28R-30005 thru 28R-7635545

28R-7235001 thru 28R-7635545

28R-7635113 thru 28R-7635545

Serial Numbers	Note
----------------	------

ALL

ALL

ALL

ALL

ALL

ALL

ALL

ALL

ALL

ALL

ALL

ALL

ALL

ALL

ALL  
ALL  
ALL

Serial Numbers	Note
ALL	
ALL	
ALL	
ALL	
ALL	
ALL	
ALL	
ALL	

Serial Numbers	Note
All	
All	
All	

All

All

All

All

All

**Serial Numbers**

**Note**

All

All

32-40000 thru 32-7640071  
32-7640066, 32-7640072 thru 32-7940282

32-40000 thru 32-40515  
32-40516 thru 32-7940282

32-4000 thru 32-7940146

All

All

32-40000 thru 32-7540198  
32-7640001 thru 32-7940282

All

32-40000 thru 32-7540139  
32-7540140 thru 32-7940282

32-40000 thru 32-7840222

**Serial Numbers**

**Note**

All

All

All

All

All

32R-7680141 thru 32R-7880068

32R-7680001 thru 32R-7880068

32R-7680001 thru 32R-7880068

All

All

All

**Serial Numbers**

**Note**

34-725001 thru 347-7450055

**1**

34-7450056 an up

**2**

All

All

**2**

All

**2**

34-725001 thru 7450055

**3**

All

All

All

All

34-7250001 thru 34-7250214

34-7250215 and up

All

All

All

All

All

All

**Models**

A,C,D,G,H,J,K

A,C,D,G,H,J,K

**Models**

A,B,C,D

A,B

C,D

E

F



## Models

E

## Models

A,F,J,K,L

A,F,J,K,L

A,B,F,J,K,L

B

C

D

C,D

D

## Models

C,H,J,K,N

C,H,J

C,H,J,K,N

F

M

F

F

M

S

S

D,U

V

D,U

V

D,U,V

E,G,P,R

E,G,P,R

E,G,P,R

## Models

B,E

B,E

C,G,H,M,P,R

C,G,H

M,P,R

C,G,H,M,P,R

D

D