

Manufacturer No.	Part No.	Make	Model	Beginning S/N	Ending S/N
PCKT-STAB-01	05-10727	Piper	PA-28-140	2820002	2820656
		Piper	PA-28-140	287225001	287225602
		Piper	PA-28-140	287125001	287125651
		Piper	PA-28-140	287425001	287425444
		Piper	PA-28-140	287325001	287325674
		Piper	PA-28-140	287625001	287625275
		Piper	PA-28-140	287725001	287725290
		Piper	PA-28-140	287525001	287525350
		Piper	PA-28-140	2820657	2826956
		Piper	PA-28-150	281	281410
		Piper	PA-28-150	281411	282171
		Piper	PA-28-150	282172	284377
		Piper	PA-28-160	281	281410
		Piper	PA-28-160	281411	282171
		Piper	PA-28-180	28725	281410
		Piper	PA-28-180	281529	282171
		Piper	PA-28-180	281411	281528
		Piper	PA-28-180	28725	281410
		Piper	PA-28-180	281411	282171
		Piper	PA-28-180	282172	284377
		Piper	PA-28-180	287205001	287205328
		Piper	PA-28-180	287105001	287105244
		Piper	PA-28-180	284378	285869
		Piper	PA-28-235	2810003	2810605
		Piper	PA-28-235	2810606	2810719
		Piper	PA-28-235	2811301	2811393
		Piper	PA-28-235	2810720	2811255
		Piper	PA-28-235	287110001	287110042
		Piper	PA-28-235	287210001	287210033
PCKT-STAB-02	05-10728	Piper	PA-28S-180	28S7105001	28S7105244
		Piper	PA-28S-180	28S7205001	28S7205328
		Piper	PA-28S-180	28S2172	28S5869
		Piper	PA-28S-180	28S671	28S2171
		Piper	PA-28S-180	28S7105001	28S7105244
		Piper	PA-28S-180	28S7205001	28S7205328
		Piper	PA-28S-180	28S2172	28S5869
PCKT-STAB-03	05-10729	Piper	PA-28-151	287715001	287715314
		Piper	PA-28-151	287515001	287515449
		Piper	PA-28-151	287415001	287415703
		Piper	PA-28-151	287615002	287615435

Manufacturer No.	Part No.	Make	Model	Beginning S/N	Ending S/N
PCKT-STAB-03	05-10729	Piper	PA-28-161	2816076	2816094
		Piper	PA-28-161	2816002	2816036
		Piper	PA-28-161	2841360	2841365
		Piper	PA-28-161	288216001	288216226
		Piper	PA-28-161	2841290	2841330
		Piper	PA-28-161	2816104	2816110
		Piper	PA-28-161	288516001	288516099
		Piper	PA-28-161	288316001	288316112
		Piper	PA-28-161	2841321	2841350
		Piper	PA-28-161	288016001	288016373
		Piper	PA-28-161	288616001	288616057
		Piper	PA-28-161	2816095	2816099
		Piper	PA-28-161	2816106	2816109
		Piper	PA-28-161	2816001	2816001
		Piper	PA-28-161	2816100	2816103
		Piper	PA-28-161	287916001	287916598
		Piper	PA-28-161	2841037	2841314
		Piper	PA-28-161	288116001	288116322
		Piper	PA-28-161	2816029	2816075
		Piper	PA-28-161	287716001	287716323
		Piper	PA-28-161	288416001	288416131
		Piper	PA-28-161	287816001	287816680
		Piper	PA-28-161	2841001	2841040
		Piper	PA-28-180	287405001	287405290
		Piper	PA-28-180	287305001	287305611
		Piper	PA-28-180	287505001	287505261
		Piper	PA-28-181	2890197	2890231
		Piper	PA-28-181	28-8690018	28-8690018
		Piper	PA-28-181	288690001	288690062
		Piper	PA-28-181	2890001	2890008
		Piper	PA-28-181	2890137	2890169
		Piper	PA-28-181	288290001	288290174
		Piper	PA-28-181	2890155	2890195
		Piper	PA-28-181	288490001	288490112
		Piper	PA-28-181	288190001	288190336
		Piper	PA-28-181	2890009	2890153
		Piper	PA-28-181	287690001	287690479
		Piper	PA-28-181	288390001	288390090
		Piper	PA-28-181	287990001	287990626
		Piper	PA-28-181	287790001	287790607

Manufacturer No.	Part No.	Make	Model	Beginning S/N	Ending S/N
PCKT-STAB-03	05-10729	Piper	PA-28-181	288090001	288090382
		Piper	PA-28-181	288590001	288590092
		Piper	PA-28-181	287890001	287890564
		Piper	PA-28-201T	287921001	287921095
		Piper	PA-28-235	287410001	287410120
		Piper	PA-28-235	287310001	287310187
		Piper	PA-28-235	287710001	287710089
		Piper	PA-28-235	287610001	287610206
		Piper	PA-28-235	287510001	287510145
		Piper	PA-28-236	288211001	288211060
		Piper	PA-28-236	288311001	288311025
		Piper	PA-28-236	288111001	288111105
		Piper	PA-28-236	2811001	2811004
		Piper	PA-28-236	288511001	288511020
		Piper	PA-28-236	2811040	2811050
		Piper	PA-28-236	288611001	288611008
		Piper	PA-28-236	2811005	2811049
		Piper	PA-28-236	287911001	287911395
		Piper	PA-28-236	288411001	288411031
		Piper	PA-28-236	288011001	288011161
PCKT-STAB-04	05-10730	Piper	PA-28R-180	28R7130001	28R7130019
		Piper	PA-28R-180	28R310878	28R31135
		Piper	PA-28R-180	28R30005	28R31087
		Piper	PA-28R-180	28R31251	28R31279
		Piper	PA-28R-200	28R7135001	28R7135238
		Piper	PA-28R-200	28R35601	28R35830
		Piper	PA-28R-200	28R35001	28R35392
PCKT-STAB-05	05-10731	Piper	PA-28R-200	28R7435001	28R7435331
		Piper	PA-28R-200	28R7635001	28R7635545
		Piper	PA-28R-200	28R7335001	28R7335455
		Piper	PA-28R-200	28R7235001	28R7235330
		Piper	PA-28R-200	28R7535001	28R7535331
		Piper	PA-28R-201	28R7837001	28R7837317
		Piper	PA-28R-201	2837001	2837049
		Piper	PA-28R-201	28R7737002	28R7737178
		Piper	PA-28R-201	2837036	2837061
		Piper	PA-28R-201T	28R7703001	28R7703427
		Piper	PA-28R-201T	28R7837001	28R7837335
		Piper	PA-28R-201T	2803001	2803015

Manufacturer No.	Part No.	Make	Model	Beginning S/N	Ending S/N
PCKT-STAB-06	05-10732	Piper	PA-28RT-201	28R8118001	28R8118082
		Piper	PA-28RT-201	28R7918001	28R7918306
		Piper	PA-28RT-201	28R8018001	28R8018116
		Piper	PA-28RT-201	28R8218001	28R8218026
		Piper	PA-28RT-201T	28R8131001	28R8131208
		Piper	PA-28RT-201T	28R8331001	28R8331051
		Piper	PA-28RT-201T	28R8031001	28R8031188
		Piper	PA-28RT-201T	28R8631001	28R8631005
		Piper	PA-28RT-201T	28R8531001	28R8531015
		Piper	PA-28RT-201T	28R8231001	28R8231080
		Piper	PA-28RT-201T	28R8631002	2831038
		Piper	PA-28RT-201T	28R7931001	28R7931353
		Piper	PA-28RT-201T	28R8431001	28R8431032
PCKT-STAB-07	05-10733	Piper	PA-32-260	327200001	327200055
		Piper	PA-32-260	321	321320
		Piper	PA-32-260	327100001	327100038
		Piper	PA-32-260	327300001	327300076
		Piper	PA-32-260	327400001	327400061
		Piper	PA-32-260	327500001	327500053
		Piper	PA-32-260	327700001	327700023
		Piper	PA-32-260	327800001	327800008
		Piper	PA-32-260	327600001	327600033
		Piper	PA-32-300	3240000	3241018
		Piper	PA-32-300	327340001	327340201
		Piper	PA-32-300	327140001	327140086
		Piper	PA-32-300	327240001	327240147
		Piper	PA-32-300	327440001	327440182
		Piper	PA-32-300	327640001	327640142
		Piper	PA-32-300	327940001	327940282
		Piper	PA-32-300	327740001	327740113
		Piper	PA-32-300	327840001	327840222
		Piper	PA-32-300	327540001	327540198
		Piper	PA-32R-300	32R7780001	32R7780549
		Piper	PA-32R-300	32R7880001	32R7880068
		Piper	PA-32R-300	32R7680001	32R7680538
PCKT-STAB-08	05-10734	Piper	PA-32S-300	32S7140001	32S7140086
		Piper	PA-32S-300	32S40000	32S41018
		Piper	PA-32S-300	32S7240001	32S7240147
		Piper	PA-32S-300	32S7240001	32S7240147

Manufacturer No.	Part No.	Make	Model	Beginning S/N	Ending S/N
PCKT-STAB-08	05-10734	Piper	PA-32S-300	32S40000	32S41018
		Piper	PA-32S-300	32S7140001	32S7140086
PCKT-STAB-09	05-10735	Piper	PA-32-301	328106001	328106110
		Piper	PA-32-301	328006001	328006116
		Piper	PA-32-301	3206004	3206019
		Piper	PA-32-301	326003	328606001
		Piper	PA-32-301	328306001	328306032
		Piper	PA-32-301	328206001	328206050
		Piper	PA-32-301	328406001	328406020
		Piper	PA-32-301	328506001	328506021
		Piper	PA-32-301	328606001	328606023
		Piper	PA-32-301T	328324001	328324016
		Piper	PA-32-301T	328024001	328024062
		Piper	PA-32-301T	328424001	328424002
		Piper	PA-32-301T	328224001	328224024
		Piper	PA-32-301T	328124001	328124046
		Piper	PA-32R-301	32R8313001	32R8313030
		Piper	PA-32R-301	32R8213001	32R8213071
		Piper	PA-32R-301	3213001	3213035
		Piper	PA-32R-301	32R8413001	32R8413024
		Piper	PA-32R-301	3213034	3213041
		Piper	PA-32R-301	32R8613001	32R8613006
		Piper	PA-32R-301	32R8013001	32R8013150
		Piper	PA-32R-301	32R8513001	32R8513016
		Piper	PA-32R-301	32R8113001	32R8113133
		Piper	PA-32R-301T	32R8629006	32R8629008
		Piper	PA-32R-301T	32R8429001	32R8429028
		Piper	PA-32R-301T	32R8629001	32R8629005
		Piper	PA-32R-301T	32R8329001	32R8329040
		Piper	PA-32R-301T	3229003	3229003
		Piper	PA-32R-301T	3229001	3229002
		Piper	PA-32R-301T	32R8129001	32R8129124
		Piper	PA-32R-301T	32R8529001	32R8529020
		Piper	PA-32R-301T	32R8029001	32R8029131
		Piper	PA-32R-301T	32R8229001	32R8229078
PCKT-STAB-10	05-10736	Piper	PA-32RT-300	32R7985001	32R7985125
		Piper	PA-32RT-300	32R7885001	32R7885302
		Piper	PA-32RT-300	32R7985001	32R7985013
		Piper	PA-32RT-300	32R7885001	32R7885302
		Piper	PA-32RT-300	32RT-7985014	32RT-7985125

Manufacturer No.	Part No.	Make	Model	Beginning S/N	Ending S/N
PCKT-STAB-10	05-10736	Piper	PA-32RT-300T	32R7887001	32R7887307
		Piper	PA-32RT-300T	32R7987001	32R7987146
		Piper	PA-32RT-300T	32R7887003	32R7887003
		Piper	PA-32RT-300T	32R7987001	32R7987035
		Piper	PA-32RT-300T	32R7887005	32R7887307
		Piper	PA-32RT-300T	32R7987004	32R7987004
		Piper	PA-32RT-300T	32R7987051	32R7987051
PCKT-STAB-11	05-10737	Piper	PA-34-200	347450001	347450024
		Piper	PA-34-200	347350001	357350353
		Piper	PA-34-200	347250001	347250360
		Piper	PA-34-200	347250025	347450220
		Piper	PA-34-200	34-7250001	34-7450024
PCKT-STAB-12	05-10739	Piper	PA-34-200T	347570001	347570337
		Piper	PA-34-200T	348170001	348170092
		Piper	PA-34-200T	347670001	347670393
		Piper	PA-34-200T	347970001	347970556
		Piper	PA-34-200T	347770001	347770441
		Piper	PA-34-200T	348070001	348070377
		Piper	PA-34-200T	347870001	347870492
		Piper	PA-34-220T	348633001	348633164
		Piper	PA-34-220T	3433021	3433172
		Piper	PA-34-220T	3433001	3433020
		Piper	PA-34-220T	348433001	348433088
		Piper	PA-34-220T	348133001	348133277
		Piper	PA-34-220T	348233001	348233215
		Piper	PA-34-220T	348333001	348333129
		Piper	PA-34-220T	348533001	348533069